DMX CHART

EK LED Blinder II IP

Model EK-EB2 IP · Prepared by Krank'd · krankd.com.au

Hire this fixture from Krank'd

1 channel | 2 channels | 3 channels | 4 channels | 5 channels | 8 channels

1-CH

1 CHANNEL	VALUE	FUNCTION
1	000-255	**Dimmer** · 0~100%

2CH

2 CHANNELS	VALUE	FUNCTION
1	000-255	**White1** · 0~100%
2	000-255	**White2** · 0~100%

3CH

3 CHANNELS	VALUE	FUNCTION
1	000-255	**Dimmer** · 0~100%
2		**Red Shift On/OFF**
	000-000	ON
	001-255	OFF
3		**Dimmer Speed Mode**
	000-051	No function
	052-101	Dimmer speed mode off (Hold 3S, override menu and change)
	102-152	Dimmer speed mode1 (Hold 3S, override menu and change)
	153-203	Dimmer speed mode2 (Hold 3S, override menu and change)
	204-255	Dimmer speed mode3 (Hold 3S, override menu and change)

4CH

4 CHANNELS	VALUE	FUNCTION
1	000-255	**White1** · 0~100%
2	000-255	**White2** · 0~100%
3		**Red Shift On/OFF**
	000-000	ON
	001-255	OFF
4		**Dimmer Speed Mode**
	000-051	No function
	052-101	Dimmer speed mode off (Hold 3S, override menu and change)
	102-152	Dimmer speed mode1 (Hold 3S, override menu and change)
	153-203	Dimmer speed mode2 (Hold 3S, override menu and change)
	204-255	Dimmer speed mode3 (Hold 3S, override menu and change)

5CH

5 CHANNELS	VALUE	FUNCTION
1	000-255	**Dimmer** · 0~100%
2		**Red Shift On/OFF**
	000-000	ON
	001-255	OFF
3		**Strobe**
	000-010	No Function
	011-132	Strobe slow to fast(All pods)
	133-255	Strobe slow to fast (Random strobe macros)
4		**Auto Programs**
	000-010	No function
	011-040	Auto 1 slow to fast
	041-080	Auto 2 slow to fast
	081-120	Auto 3 slow to fast
	121-160	Auto 4 slow to fast
	161-200	Auto 5 slow to fast
	201-240	Auto 6 Slow to fast
	241-255	No function
5		**Dimmer Speed Mode**
	000-051	No function
	052-101	Dimmer speed mode off (Hold 3S, override menu and change)
	102-152	Dimmer speed mode1 (Hold 3S, override menu and change)
	153-203	Dimmer speed mode2 (Hold 3S, override menu and change)
	204-255	Dimmer speed mode3 (Hold 3S, override menu and change)

8CH

8 CHANNELS	VALUE	FUNCTION
1	000-255	**Dimmer** · 0~100%
2	000-255	**Dimmer Fine** · 0~100%
3		**Red Shift On/OFF**
	000-000	ON
	001-255	OFF
4		**Strobe**
	000-010	No Function
	011-132	Strobe slow to fast(All pods)
	133-255	Strobe slow to fast (Random strobe macros)
5	000-255	**White 1** · 0~100%
6	000-255	**White 2** · 0~100%
7		**Auto Programs**
	000-010	No function
	011-040	Auto 1 slow to fast

8 CHANNELS	VALUE	FUNCTION
	041-080	Auto 2 slow to fast
	081-120	Auto 3 slow to fast
	121-160	Auto 4 slow to fast
	161-200	Auto 5 slow to fast
	201-240	Auto 6 Slow to fast
	241-255	No function
8		**Dimmer Speed Mode**
	000-051	No function
	052-101	Dimmer speed mode off (Hold 3S, override menu and change)
	102-152	Dimmer speed mode1 (Hold 3S, override menu and change)
	153-203	Dimmer speed mode2 (Hold 3S, override menu and change)
	204-255	Dimmer speed mode3 (Hold 3S, override menu and change)