DMX CHART

ACME CM-700Z

Model GLAMOUR 700Z · Prepared by Krank'd · krankd.com.au

Hire this fixture from Krank'd

15ch 27ch 17ch 15+ Channels

15 Channels (Mode 1)

15CH	VALUE	FUNCTION
1	000–255	**Pan** · 0° → 540°
2	000–255	**Pan Fine**
3	000–255	**Tilt** · 0° → 220°
4	000–255	**Tilt Fine**
5	000–255	**Pan/Tilt Speed** · Fast to Slow
6		**Special Functions**
	000–009	Null
	010–014	Reset
	015–255	Null
7	000–255	**Dimmer** · 0% → 100%
8	000–255	**Dimmer Fine**
9		**Shutter**
	000–019	Close
	020–024	Open
	025–064	Strobe 1: fast → slow
	065–069	Open
	070–084	Strobe 2: opening pulse, fast → slow
	085–089	Open
	090–104	Strobe 3: closing pulse, fast → slow
	105–109	Open
	110–124	Strobe 4: random strobe, fast → slow
	125–129	Open
	130–144	Strobe 5: random closing pulse, fast → slow
	145–149	Open
	150–164	Strobe 6: random opening pulse, fast → slow
	165–169	Open
	170–184	Strobe 7: burst pulse, fast → slow
	185–189	Open
	190–204	Strobe 8: random burst pulse, fast → slow
	205–209	Open
	210–224	Strobe 9: sine wave, fast → slow
	225–229	Open
	230–244	Strobe 10: burst, fast → slow
	245–255	Open
10	000–255	**Red** · 0% → 100%
11	000–255	**Green** · 0% → 100%

15CH	VALUE	FUNCTION
12	000-255	**Blue** · 0% → 100%
13	000-255	**White** · 0% → 100%
14		**Color Macro**
	000-009	Null
	010-014	Color 1
	015-019	Color 2
	020-024	Color 3
	025-029	Color 4
	030-034	Color 5
	035-039	Color 6
	040-044	Color 7
	045-049	Color 8
	050-054	Color 9
	055-059	Color 10
	060-064	Color 11
	065-069	Color 12
	070-074	Color 13
	075-079	Color 14
	080-084	Color 15
	085-089	Color 16
	090-094	Color 17
	095-099	Color 18
	100-104	Color 19
	105-109	Color 20
	110-114	Color 21
	115-119	Color 22
	120-124	Color 23
	125-129	Color 24
	130-134	Color 25
	135-139	Color 26
	140-144	Color 27
	145-149	Color 28
	150-154	Color 29
	155-159	Color 30
	160-164	Color 31
	165-169	Color 32
	170-174	Color 33
	175-179	Open
	180-201	Color 33 → Color 1
	202-207	Stop
	208-229	Color 1 → Color 33

15CH	VALUE	FUNCTION
	230-234	Open
	235-239	Fast
	240-244	Medium
	245-249	Slow
	250-255	Open
15	000-255	**Zoom** · Wide → Narrow

27 Channels (Mode 2)

27CH	VALUE	FUNCTION
1	000-255	**Pan** · 0° → 540°
2	000-255	**Pan Fine**
3	000-255	**Tilt** · 0° → 220°
4	000-255	**Tilt Fine**
5	000-255	**Pan/Tilt Speed** · Fast to Slow
6	000-255	**Zoom** · Wide → Narrow
7		**Special Functions**
	000-009	Null
	010-014	Reset
	015-255	Null
8	000-255	**Dimmer** · 0% → 100%
9	000-255	**Dimmer Fine**
10		**Shutter**
	000-019	Close
	020-024	Open
	025-064	Strobe 1: fast → slow
	065-069	Open
	070-084	Strobe 2: opening pulse, fast → slow
	085-089	Open
	090-104	Strobe 3: closing pulse, fast → slow
	105-109	Open
	110-124	Strobe 4: random strobe, fast → slow
	125-129	Open
	130-144	Strobe 5: random closing pulse, fast → slow
	145-149	Open
	150-164	Strobe 6: random opening pulse, fast → slow
	165-169	Open
	170-184	Strobe 7: burst pulse, fast → slow
	185-189	Open
	190-204	Strobe 8: random burst pulse, fast → slow
	205-209	Open
	210-224	Strobe 9: sine wave, fast → slow
	225-229	Open

27CH	VALUE	FUNCTION
	230-244	Strobe 10: burst, fast → slow
	245-255	Open
11	000-255	**Red 1** · 0% → 100%
12	000-255	**Green 1** · 0% → 100%
13	000-255	**Blue 1** · 0% → 100%
14	000-255	**White 1** · 0% → 100%
15		**Color Macro 1**
	000-009	Null
	010-017	Color 1
	018-024	Color 2
	025-032	Color 3
	033-039	Color 4
	040-047	Color 5
	048-054	Color 6
	055-061	Color 7
	062-069	Color 8
	070-076	Color 9
	077-084	Color 10
	085-091	Color 11
	092-099	Color 12
	100-106	Color 13
	107-113	Color 14
	114-121	Color 15
	122-128	Color 16
	129-136	Color 17
	137-143	Color 18
	144-151	Color 19
	152-158	Color 20
	159-165	Color 21
	166-173	Color 22
	174-180	Color 23
	181-188	Color 24
	189-195	Color 25
	196-203	Color 26
	204-210	Color 27
	211-217	Color 28
	218-225	Color 29
	226-232	Color 30
	233-240	Color 31
	241-247	Color 32
	248-255	Color 33

27CH	VALUE	FUNCTION
16	000-255	**Red 2** · 0% → 100%
17	000-255	**Green 2** · 0% → 100%
18	000-255	**Blue 2** · 0% → 100%
19	000-255	**White 2** · 0% → 100%
20	000-255	**Color Macro 2** · (Same as Color Macro 1)
21	000-255	**Red 3** · 0% → 100%
22	000-255	**Green 3** · 0% → 100%
23	000-255	**Blue 3** · 0% → 100%
24	000-255	**White 3** · 0% → 100%
25	000-255	**Color Macro 3** · (Same as Color Macro 1)
26		**Macro Effect Select**
	000-007	Null
	008-022	Built-in Effect 1
	023-037	Built-in Effect 2
	038-052	Built-in Effect 3
	053-067	Built-in Effect 4
	068-082	Built-in Effect 5
	083-097	Built-in Effect 6
	098-112	Built-in Effect 7
	113-127	Built-in Effect 8
	128-142	Built-in Effect 9
	143-157	Built-in Effect 10
	158-172	Built-in Effect 11
	173-187	Built-in Effect 12
	188-202	Built-in Effect 13
	203-217	Built-in Effect 14
	218-232	Built-in Effect 15
	233-247	Built-in Effect 16
	248-255	Built-in Effect 17
27	000-255	**Macro Effect Speed** · Slow to Fast

17 Channels (Mode 3)

17CH	VALUE	FUNCTION
1	000-255	**Pan** · 0° → 540°
2	000-255	**Pan Fine**
3	000-255	**Tilt** · 0° → 220°
4	000-255	**Tilt Fine**
5	000-255	**Pan/Tilt Speed** · Fast to Slow
6		**Special Functions**
	000-009	Null
	010-014	Reset

17CH	VALUE	FUNCTION
	015-255	Null
7	000-255	**Dimmer** · 0% → 100%
8	000-255	**Dimmer Fine**
9		**Shutter**
	000-019	Close
	020-024	Open
	025-064	Strobe 1: fast → slow
	065-069	Open
	070-084	Strobe 2: opening pulse, fast → slow
	085-089	Open
	090-104	Strobe 3: closing pulse, fast → slow
	105-109	Open
	110-124	Strobe 4: random strobe, fast → slow
	125-129	Open
	130-144	Strobe 5: random closing pulse, fast → slow
	145-149	Open
	150-164	Strobe 6: random opening pulse, fast → slow
	165-169	Open
	170-184	Strobe 7: burst pulse, fast → slow
	185-189	Open
	190-204	Strobe 8: random burst pulse, fast → slow
	205-209	Open
	210-224	Strobe 9: sine wave, fast → slow
	225-229	Open
	230-244	Strobe 10: burst, fast → slow
	245-255	Open
10	000-255	**Red** · 0% → 100%
11	000-255	**Green** · 0% → 100%
12	000-255	**Blue** · 0% → 100%
13	000-255	**White** · 0% → 100%
14		**Color Macro**
	000-009	Null
	010-014	Color 1
	015-019	Color 2
	020-024	Color 3
	025-029	Color 4
	030-034	Color 5
	035-039	Color 6
	040-044	Color 7
	045-049	Color 8
	050-054	Color 9

17CH	VALUE	FUNCTION
	055-059	Color 10
	060-064	Color 11
	065-069	Color 12
	070-074	Color 13
	075-079	Color 14
	080-084	Color 15
	085-089	Color 16
	090-094	Color 17
	095-099	Color 18
	100-104	Color 19
	105-109	Color 20
	110-114	Color 21
	115-119	Color 22
	120-124	Color 23
	125-129	Color 24
	130-134	Color 25
	135-139	Color 26
	140-144	Color 27
	145-149	Color 28
	150-154	Color 29
	155-159	Color 30
	160-164	Color 31
	165-169	Color 32
	170-174	Color 33
	175-179	Open
	180-201	Color 33 → Color 1
	202-207	Stop
	208-229	Color 1 → Color 33
	230-234	Open
	235-239	Fast
	240-244	Medium
	245-249	Slow
	250-255	Open
15	000-255	**Zoom** · Wide → Narrow
16		**Macro Effect Select**
	000-007	Null
	008-016	Built-in Effect 1
	017-025	Built-in Effect 2
	026-034	Built-in Effect 3
	035-043	Built-in Effect 4
	044-052	Built-in Effect 5

17CH	VALUE	FUNCTION
	053-061	Built-in Effect 6
	062-070	Built-in Effect 7
	071-079	Built-in Effect 8
	080-088	Built-in Effect 9
	089-097	Built-in Effect 10
	098-106	Built-in Effect 11
	107-115	Built-in Effect 12
	116-124	Built-in Effect 13
	125-133	Built-in Effect 14
	134-142	Built-in Effect 15
	143-151	Built-in Effect 16
	152-160	Built-in Effect 17
	161-169	Built-in Effect 18
	170-178	Built-in Effect 19
	179-187	Built-in Effect 20
	188-196	Built-in Effect 21
	197-205	Built-in Effect 22
	206-214	Built-in Effect 23
	215-223	Built-in Effect 24
	224-232	Built-in Effect 25
	233-241	Built-in Effect 26
	242-250	Built-in Effect 27
	251-255	Built-in Effect 28
17		**Macro Effect Speed**
	000-127	Slow to Fast without Fade
	128-255	Slow to Fast with Fade

15+ Channels (Mode 4)

15+ CHANNELS	VALUE	FUNCTION
1	000-255	**Pan** · 0° → 540°
2	000-255	**Pan Fine**
3	000-255	**Tilt** · 0° → 220°
4	000-255	**Tilt Fine**
5	000-255	**Pan/Tilt Speed** · Fast to Slow
6		**Special Functions**
	000-009	Null
	010-014	Reset
	015-255	Null
7	000-255	**Dimmer** · 0% → 100%
8		**Shutter**
	000-019	Close

15+ CHANNELS	VALUE	FUNCTION
	020-024	Open
	025-064	Strobe 1: fast → slow
	065-069	Open
	070-084	Strobe 2: opening pulse, fast → slow
	085-089	Open
	090-104	Strobe 3: closing pulse, fast → slow
	105-109	Open
	110-124	Strobe 4: random strobe, fast → slow
	125-129	Open
	130-144	Strobe 5: random closing pulse, fast → slow
	145-149	Open
	150-164	Strobe 6: random opening pulse, fast → slow
	165-169	Open
	170-184	Strobe 7: burst pulse, fast → slow
	185-189	Open
	190-204	Strobe 8: random burst pulse, fast → slow
	205-209	Open
	210-224	Strobe 9: sine wave, fast → slow
	225-229	Open
	230-244	Strobe 10: burst, fast → slow
	245-255	Open
9	000-255	**Red** · 0% → 100%
10	000-255	**Green** · 0% → 100%
11	000-255	**Blue** · 0% → 100%
12	000-255	**White** · 0% → 100%
13		**Color Macro**
	000-009	Null
	010-017	Color 1
	018-024	Color 2
	025-032	Color 3
	033-039	Color 4
	040-047	Color 5
	048-054	Color 6
	055-061	Color 7
	062-069	Color 8
	070-076	Color 9
	077-084	Color 10
	085-091	Color 11
	092-099	Color 12
	100-106	Color 13
	107-113	Color 14

15+ CHANNELS	VALUE	FUNCTION
	114-121	Color 15
	122-128	Color 16
	129-136	Color 17
	137-143	Color 18
	144-151	Color 19
	152-158	Color 20
	159-165	Color 21
	166-173	Color 22
	174-180	Color 23
	181-188	Color 24
	189-195	Color 25
	196-203	Color 26
	204-210	Color 27
	211-217	Color 28
	218-225	Color 29
	226-232	Color 30
	233-240	Color 31
	241-247	Color 32
	248-255	Color 33
14	000-255	**Zoom** · Wide → Narrow
15		**Macro Effect Select**
	000-031	Null
	032-047	Built-in Effect 1
	048-063	Built-in Effect 2
	064-079	Built-in Effect 3
	080-095	Built-in Effect 4
	096-111	Built-in Effect 5
	112-127	Built-in Effect 6
	128-143	Built-in Effect 7, Slow to Fast
	144-159	Built-in Effect 8, Slow to Fast
	160-175	Built-in Effect 9, Slow to Fast
	176-191	Built-in Effect 10, Slow to Fast
	192-207	Built-in Effect 11, Slow to Fast
	208-223	Built-in Effect 12, Slow to Fast
	224-239	Built-in Effect 13, Slow to Fast
	240-255	Built-in Effect 14, Slow to Fast