DMX CHART

ACME Stage Par Zoom Colour

Model BL-100Z RGBL · Prepared by Krank'd · krankd.com.au

13ch 19ch 42ch

Hire this fixture from Krank'd

13 Channel

13CH	VALUE	FUNCTION
1	000-255	**Red**
2	000-255	**Green**
3	000-255	**Blue**
4	000-255	**Lemon**
5	000-255	**Dimmer Intensity** · Dimmer Intensity:Intensity 0 to 100%
6	000-255	**Dimmer Fine** · Dimmer Fine: 0 to 100%
7	000-255	**Zoom** · Zoom: Zoom adjustment from wide to narrow
8	000-255	**Backlight_Red_Dimmer**
9	000-255	**Backlight_Green_Dimmer**
10	000-255	**Backlight_Blue_Dimmer**
11	000-255	**Backlight_White_Dimmer**
12	000-255	**Backlight_Dimmer Intensity** · Backlight_Dimmer Intensity:Intensity 0 to 100%
13	000-255	**Backlight_ Dimmer Fine** · Backlight_ Dimmer Fine: 0 to 100%

19 Channel

19CH	VALUE	FUNCTION
1	000-255	**Red**
2	000-255	**Green**
3	000-255	**Blue**
4	000-255	**Lemon**
5		**Color mocro**
	000-009	No Base Color
	010-017	Color1
	018-024	Color2
	025-032	Color3
	033-039	Color4
	040-047	Color5
	048-054	Color6
	055-061	Color7
	062-069	Color8
	070-076	Color9
	077-084	Color10
	085-091	Color11
	092-099	Color12
	100-106	Color13
	107-113	Color14

19CH	VALUE	FUNCTION
	114-121	Color15
	122-128	Color16
	129-136	Color17
	137-143	Color18
	144-151	Color19
	152-158	Color20
	159-165	Color21
	166-173	Color22
	174-180	Color23
	181-188	Color24
	189-195	Color25
	196-203	Color26
	204-210	Color27
	211-217	Color28
	218-225	Color29
	226-232	Color30
	233-240	Color31
	241-247	Color32
	248-255	Color33
6	000-255	**CTO**
7	000-255	**Dimmer Intensity** · Dimmer Intensity:Intensity 0 to 100%
8	000-255	**Dimmer Fine** · Dimmer Fine: 0 to 100%
9		**Shutter, Strobe**
	000-007	Close
	008-015	Open
	016-131	Strobe Slow->Fast
	132-139	Open
	140-181	Fast Close Slow Open
	182-189	Open
	190-231	Fast Open Slow Close
	232-239	Open
	240-247	Random Strobe
	248-255	Open
10	000-255	**Zoom** · Zoom: Zoom adjustment from wide to narrow
11	000-255	**Backlight_Red_Dimmer**
12	000-255	**Backlight_Green_Dimmer**
13	000-255	**Backlight_Blue_Dimmer**
14	000-255	**Backlight_White_Dimmer**
15		**Backlight_Color mocro**
	000-009	No Base Color
	010-017	Color1

19CH	VALUE	FUNCTION
	018-024	Color2
	025-032	Color3
	033-039	Color4
	040-047	Color5
	048-054	Color6
	055-061	Color7
	062-069	Color8
	070-076	Color9
	077-084	Color10
	085-091	Color11
	092-099	Color12
	100-106	Color13
	107-113	Color14
	114-121	Color15
	122-128	Color16
	129-136	Color17
	137-143	Color18
	144-151	Color19
	152-158	Color20
	159-165	Color21
	166-173	Color22
	174-180	Color23
	181-188	Color24
	189-195	Color25
	196-203	Color26
	204-210	Color27
	211-217	Color28
	218-225	Color29
	226-232	Color30
	233-240	Color31
	241-247	Color32
	248-255	Color33
16	000-255	**Backlight_Dimmer Intensity** · Backlight_Dimmer Intensity:Intensity 0 to 100%
17		**Backlight_Shutter, Strobe**
	000-007	Close
	008-015	Open
	016-131	Strobe Slow->Fast
	132-139	Open
	140-181	Fast Close Slow Open
	182-189	Open
	190-231	Fast Open Slow Close

19CH	VALUE	FUNCTION
	232-239	Open
	240-247	Random Strobe
	248-255	Open
18		**Backlight_Macro**
	000-055	No function
	056-065	Macro1
	066-075	Macro2
	076-085	Macro3
	086-095	Macro4
	096-105	Macro5
	106-115	Macro6
	116-125	Macro7
	126-135	Macro8
	136-145	Macro9
	146-155	Macro10
	156-165	Macro11
	166-175	Macro12
	176-185	Macro13
	186-195	Macro14
	196-205	Macro15
	206-215	Macro16
	216-225	Macro17
	226-235	Macro18
	236-245	Macro19
	246-255	Macro20
19	000-255	**Backlight_Macro_Speed**

42 Channel

42CH	VALUE	FUNCTION
1	000-255	**Red**
2	000-255	**Green**
3	000-255	**Blue**
4	000-255	**Lemon**
5		**Color mocro**
	000-009	No Base Color
	010-017	Color1
	018-024	Color2
	025-032	Color3
	033-039	Color4
	040-047	Color5
	048-054	Color6
	055-061	Color7

42CH	VALUE	FUNCTION
	062-069	Color8
	070-076	Color9
	077-084	Color10
	085-091	Color11
	092-099	Color12
	100-106	Color13
	107-113	Color14
	114-121	Color15
	122-128	Color16
	129-136	Color17
	137-143	Color18
	144-151	Color19
	152-158	Color20
	159-165	Color21
	166-173	Color22
	174-180	Color23
	181-188	Color24
	189-195	Color25
	196-203	Color26
	204-210	Color27
	211-217	Color28
	218-225	Color29
	226-232	Color30
	233-240	Color31
	241-247	Color32
	248-255	Color33
6	000-255	**CTO**
7	000-255	**Dimmer Intensity** · Dimmer Intensity:Intensity 0 to 100%
8	000-255	**Dimmer Fine** · Dimmer Fine: 0 to 100%
9		**Shutter, Strobe**
	000-007	Close
	008-015	Open
	016-131	Strobe Slow->Fast
	132-139	Open
	140-181	Fast Close Slow Open
	182-189	Open
	190-231	Fast Open Slow Close
	232-239	Open
	240-247	Random Strobe
	248-255	Open
10	000-255	**Zoom** · Zoom: Zoom adjustment from wide to narrow

42CH	VALUE	FUNCTION
11	000-255	**Backlight_Red1**
12	000-255	**Backlight_Green1**
13	000-255	**Backlight_Blue1**
14	000-255	**Backlight_White1**
15	000-255	**Backlight_Red2**
16	000-255	**Backlight_Green2**
17	000-255	**Backlight_Blue2**
18	000-255	**Backlight_White2**
19	000-255	**Backlight_Red3**
20	000-255	**Backlight_Green3**
21	000-255	**Backlight_Blue3**
22	000-255	**Backlight_White3**
23	000-255	**Backlight_Red4**
24	000-255	**Backlight_Green4**
25	000-255	**Backlight_Blue4**
26	000-255	**Backlight_White4**
27	000-255	**Backlight_Red5**
28	000-255	**Backlight_Green5**
29	000-255	**Backlight_Blue5**
30	000-255	**Backlight_White5**
31	000-255	**Backlight_Red6**
32	000-255	**Backlight_Green6**
33	000-255	**Backlight_Blue6**
34	000-255	**Backlight_White6**
35	000-255	**Backlight_Red7**
36	000-255	**Backlight_Green7**
37	000-255	**Backlight_Blue7**
38	000-255	**Backlight_White7**
39	000-255	**Backlight_Red8**
40	000-255	**Backlight_Green8**
41	000-255	**Backlight_Blue8**
42	000-255	**Backlight_White8**

※ Color macro / Backlight_Color macro list the same 33 colors on channels 5 and 15 of the 19-channel mode and channel 5 of the 42-channel mode.

※ Source misprint corrected: the manual prints 'Opne' for the strobe-open state (ch9 / ch17 / Backlight_Shutter); this chart prints 'Open'.