DMX CHART

TourPro Zoom Par Junior

Prepared by Krank'd · krankd.com.au

Hire this fixture from Krank'd

2ch 4ch 8ch 17ch 19ch

2 DMX Channel

2CH	VALUE	FUNCTION
1	000-255	**51 static color**
2	000-255	**ZOOM**

4 DMX Channel

4CH	VALUE	FUNCTION
1	000-255	**master dimmer**
2	000-255	**Hue**
3	000-255	**Staturation**
4	000-255	**zoom min to max**

8 DMX Channel

8CH	VALUE	FUNCTION
1	000-255	**Master dimmer**
2	000-255	**red**
3	000-255	**green**
4	000-255	**blue**
5	000-255	**white**
6		**strobe**
	000-008	no function
	009-255	strobe from slow to fast
7	000-255	**zoom min to max**
8	000-255	**motor speed**

17 DMX Channel

17CH	VALUE	FUNCTION
1	000-255	**Master dimmer**
2	000-255	**No function**
3	000-255	**Red hight 8 byte**
4	000-255	**Red low 8 byte**
5	000-255	**Green hight 8 byte**
6	000-255	**Green low 8 byte**
7	000-255	**Blue hight 8 byte**
8	000-255	**Blue low 8 byte**
9	000-255	**White hight 8 byte**
10	000-255	**White low 8 byte**
11		**dimmer speed**
	000-049	Default dimmer

17CH	VALUE	FUNCTION
	050-099	dimmer speed 1
	100-149	dimmer speed 2
	150-199	dimmer speed 3
	200-255	dimmer speed 4
12		**strobe**
	000-008	no function
	009-255	strobe from slow to fast
13	000-255	**zoom min to max**
14	000-255	**motor speed**
15		**program**
	000-007	Default
	008-010	program 1
	011-020	program 2
	021-030	program 3
	031-040	program 4
	041-050	program 5
	051-060	program 6
	061-070	program 7
	071-080	program 8
	081-090	program 9
	091-100	program 10
	101-109	program 11
	110-255	None
16	000-255	**auto speed**
17	201-220	**motor reset**

19 DMX Channel

19CH	VALUE	FUNCTION
1	000-255	**Master dimmer**
2	000-255	**No function**
3	000-255	**Red hight 8 byte**
4	000-255	**Red low 8 byte**
5	000-255	**Green hight 8 byte**
6	000-255	**Green low 8 byte**
7	000-255	**Blue hight 8 byte**
8	000-255	**Blue low 8 byte**
9	000-255	**White hight 8 byte**
10	000-255	**White low 8 byte**
11		**dimmer speed**
	000-049	Default dimmer
	050-099	dimmer speed 1

19CH	VALUE	FUNCTION
	100-149	dimmer speed 2
	150-199	dimmer speed 3
	200-255	dimmer speed 4
12	000-255	**36 macros color**
13		**strobe**
	000-008	no function
	009-255	strobe from slow to fast
14	000-255	**zoom min to max**
15	000-255	**motor speed**
16	000-255	**ID number(0-66)**
17		**program**
	000-007	Default
	008-010	program 1
	011-020	program 2
	021-030	program 3
	031-040	program 4
	041-050	program 5
	051-060	program 6
	061-070	program 7
	071-080	program 8
	081-090	program 9
	091-100	program 10
	101-109	program 11
	110-255	None
18	000-255	**auto speed**
19	201-220	**motor reset**

※ The 2 DMX Channel table prints only Channel + Function (no value column); each channel is its full 000-255 range.

※ Channel 17 (17ch mode) / Channel 19 (19ch mode) 'motor reset' is only assigned the 201-220 range in the source; values outside that band are left unlabelled.

※ Function names are spelled as TourPro prints them (for example 'hight', 'Staturation', 'macros color').